



User Manual

Thank you for purchasing this product! To use this product correctly, please read these instructions carefully before use and strictly follow the guidelines and precautions. Store these instructions in a safe place for future reference.
 Mobile phones and other portable electronic devices occasionally overheat and fail to operate properly, especially when used in hot environments. Powered by advanced cooling technology, the TRUNK Phone Cooler is designed to draw heat away from your devices and dissipate it with a powerful, silent 7-blade fan, ensuring maximum airflow with minimal noise. Perfect for gamers, YouTubers, videographers, live streamers, fitness creators, bloggers, bloggers, YouTubers, interviewees, and others who use devices for extended periods.


PARAMETERS

Product Name: Phone Cooler
 Product Model: TCD-K20
 Charging Current: 5V, 2A
 Battery Capacity: 2100mAh
 Interface: Type-C
 Net Weight: 126g/2.2oz
 Battery Weight: 136g/3.0oz
 Dimension: 8.2x6cm/3.2x2.4in
 Application: All 3rd-Generation Devices

FEATURES


- Advanced Cooling Technology
- LED Temperature Display
- Rechargeable Battery
- 7-Blade Fan
- RGB LED
- Universal Clamp
- Ultra-quiet

PRODUCT ILLUSTRATION



INSTRUCTIONS

- 1. Remove the back cover (to battery pack)
- 1. Attach the power bank to the product (D)
- 2. Clamp the product to the back of your device
- *When rotating, be careful not to block the bottom on the side of the phone.
- 3. Double check your device is securely attached.
- 4. Click the ON/OFF button to turn on the product.



20 Lightweight Model (Powered by power cable)

- 1. Remove the power bank from the product (D)
- 2. Clamp the product to the back of your device
- *When rotating, be careful not to block the bottom on the side of the phone.
- 3. Double check your device is securely attached.
- 4. Plug in the power cable.
- 5. Click the ON/OFF button to turn on the product.

*The cooling ability is affected by the barrier of the phone case. To maintain the best cooling effect, we strongly recommend removing the phone case when using this product. *This product does not have an internal battery and must be plugged in when in use. *If your product does not work after connecting the power, check if the adapter output is 5V, 2A.

CAUTION

- 1. Do not use the battery pack attached. The indicator light will be red when charging and the light will turn off when completely charged. The product turns off automatically when the battery runs out.
- 2. Do not use the product for more than 2.5 hours.
- *The power bank cannot charge separately.
- 20 Lightweight Model (Battery Pack removed): The indicator light will turn red after the power is connected.

CONTENTS

- Phone Cooler _____ x1
- 2100mAh Power Bank _____ x1
- Type-C Power Cable (5m/15ft) _____ x1
- User Manual _____ x1

CLEANING AND MAINTENANCE

Clean this product with a slightly moistened soft cloth. Do not use strong oxidizing or caustic detergents. Never immerse the device in water (danger of short circuit).

WARNING

- *Do not use this product to use this product, keep it away from babies.
- *Do not use the device with water and do not use in water.
- *Do not use chemical solvents such as gasoline or alcohol to wipe the body.
- *Do not disassemble, repair, or modify this product.
- *Do not use this product in an environment that is in any way hazardous, flammable, or explosive.
- *To prevent any personal and property damage, do not insert your fingers or any foreign substance into the air vent.

DISPOSAL

This device bears the symbol for separate collection of waste due to electrical and electronic equipment. Therefore, this product must be recycled or disposed in order to protect the environment. Please contact your local authority for further information about how to dispose of the product. Electronic products that are not collected separately contribute a potential risk to the environment and human health because of the hazardous substances contained in such equipment.

WARRANTY

We provide a 12-month warranty on this product, which is calculated from the date of purchase. During the warranty period, we will replace parts or the entire product which have failed due to the material or the production process. If the device is broken or faulty, consult our after-sales team. Do not attempt to repair the device yourself.